


# SECTION 6: REPLACEMENT PARTS

## K3000™ & K4000® TORCH REPLACEMENT PARTS



TORCH REPLACEMENT PARTS LIST			
Item	Description	K3000™	K4000®
1	Insulators & Screws	94-433-193	94-433-183
2	Lever & Screw	94-476-080	94-476-066
3	Valve Bonnet	94-104-016	94-104-016
4	Bonnet Wrench	94-960-001	94-960-001
5	Bonnet Only	94-104-012	94-104-012
6	Spool & O-Rings	94-801-011	94-801-011
7	O-Ring	94-710-036	94-710-036
8	Spool Only	94-801-010	94-801-010
9	Upper Arm	94-048-120	94-048-088
10	Head & Screw	94-378-366	94-378-368
11	Torch Body	94-103-232	94-103-206
12	Hinge Pin	94-632-101	94-632-094
13	Spring	94-800-191	94-800-077
14	Handle	94-370-179	94-370-163